


JLCJLCJLCJLC

Backplane: W2 Card: Controller L




LA LB LC LD LJ1 LJ2 LM1 LM2 LX LY LX Y LIN LC LIC LPC LA SA LB SB LC SC LD SD SJ SM1 SM2 SM SX SY SXY

Ctrl-Z

Ctrl-Y

Ctrl-X



W2 BACKPLANE CONTROLLER CARD : GOTO & MOV8/16